

CABIN AIR FILTERS

Passenger Compartment Air Filter - Vue


REMOVAL & INSTALLATION

NOTE: Manufacturer's terminology for this filter is passenger compartment air filter or cabin air filter.

CABIN AIR FILTER

Removal & Installation (2002-2006)

1. Open hood. Remove the push pins from air filter access panel. See **Fig. 1**.
2. Remove the passenger compartment air filter access panel. See **Fig. 1**.



G00214527

Fig. 1: Removing Passenger Compartment Air Filter
Courtesy of GENERAL MOTORS CORP.

3. Remove the passenger compartment air filter from the housing.
4. To install passenger compartment air filter, reverse removal procedure.