#### 2003-04 ENGINE COOLING

### Specifications & Drive Belt Routing - Vue

### **ADJUSTMENTS**

CAUTION: When battery is disconnected, vehicle computer and memory systems may lose memory data. Driveability problems may exist until computer systems have completed a relearn cycle. See appropriate COMPUTER RELEARN PROCEDURES article in GENERAL INFORMATION before disconnecting battery.

#### **BELT ADJUSTMENT**

Application	<sup>(1)</sup> In. (mm)
Serpentine Belt	(1)
(1) Belt tension is maintained automatically by a spring-tensioned idler pulley. No adjustment is necessary.	

### **DRIVE BELT ROUTING**

NOTE: For serpentine belt routing, see underhood label or refer to appropriate

illustrations. See Fig. 1 and Fig. 2.




Fig. 1: Serpentine Belt Routing (4-Cylinder) Courtesy of GENERAL MOTORS CORP.




Fig. 2: Serpentine Belt Routing (V6)
Courtesy of GENERAL MOTORS CORP.

# **TROUBLE SHOOTING**

NOTE: For electric cooling fan diagnosis and testing, see appropriate ELECTRIC

COOLING FANS article. For cooling system removal and installation procedures, see appropriate REMOVAL & INSTALLATION article.

# **COOLING SYSTEM SPECIFICATIONS**

### **COOLING SYSTEM SPECIFICATIONS**

Application	Specification
Coolant Replacement Interval	100,000 Miles Or 5 Years Whichever Comes First

Coolant Capacity	
4-Cylinder	7.4 Qts. (7.0L)
V6	9.7 Qts. (9.2L)
Thermostat Opening Temperature	
4-Cylinder	185°F (82°C)
V6	195°F (91°C)